



Fusion 7.02 Upgrade Program Installation

Special Note: You will need one compact flash card and one compact flash reader/writer. Be sure your Fusion is charged before updating. Updating the programming on your Fusion unit will erase all files. Please download important files prior to reprogramming your Fusion keyboard.

Steps:

- Copy the two files, DISK.BIN AND KERN.BIN to a compact flash card
- Now slide the Compact Flash (CF) card into the slot in the rear of the Fusion. (Push until firmly seated)
- Press the “Reset” button (the smallest hole in the back of the unit).
- On the Fusion screen, you’ll see the program being loaded. When done, the screen will say, “Remove Flash Card. Press ON to Reboot.”
- Remove the Flash Card and press ON/OFF

You’re all set. You now have all the latest Fusion programming on your Fusion unit.

If you have any questions, please don’t hesitate to call or email. We’ll be happy to assist you.

Fusion@writerlearning.com

(800) 797-7121